

NOTE:
 Connect to Existing 20" Pipe Using an AWWA C906 Approved HDPE to MJ Adapter as Provided by Scarborough Supply Co. of Whitby, Ontario, Canada or Approved Equal.

Sta. 0+00.00 SS Line 1 =
 B.L. Sta 7+27.191, 38.58 Rt.
 N. 1697923.39, E. 1601883.12
 BEGIN SS Line 1 Construction
 Connect to Existing PVC Pipe
 Using HDPE to MJ Adapter.
 Install 1- 20" HDPE 3-Segment
 45' EI (DR9)(Rt)

DANGER!
 GAS LINE
 CROSSES

CAUTION!
 Ex. AT&T (x2)
 Ex Wtr
 Ex. 14" SS FM
 Ex. 21" PVC SS
 Crosses

CAUTION!
 Ex. 60" Wtr
 Crosses

Sta. 5+38.08 SS Line 1 =
 B.L. Sta 12+46.94, 40.00 Lt.
 N. 1698441.76, E. 1601795.79,
 Deflect Pipe 13' 47' 02" (Rt.)
 End Trenchless Installation

Sta. 10+41.14 SS Line 1=
 B.L. Sta 17+50.00, 40.00' Lt.
 N.1698944.78' E.1601789.39
 Install 1-20" End Cap
 END PROJECT

