



Sta. 0+34.27, SWS Line Ic =  
€ Sta. 98+85.00, 37.75' Lt.  
Construct Inlet (Single)(Type 1)  
(6'-4" x 4'-4")  
Install 15' x 76.50'  
Storm Sewer (RCP) (E)  
See Sh. No's 90, 96 & 97.

Sta. 0+00.00, Begin SWS Line Ic =  
€ Sta. 98+74.32, 70.31' Lt.  
Install 15' x 34.27'  
Storm Sewer (RCP) (E)  
Remove Temporary Pipe Plug and  
Connect to Existing 15" RCP  
with Concrete Collar. Cast of collar  
Subsidiary to pipe installation.  
See Sh. No's 50 & 97.

Sta. 1+10.77, End SWS Line Ic =  
Sta. 3+34.99, SWS Line I =  
€ Sta. 98+85.00, 38.75' Rt.

Sta. 0+00.00, Begin SWS Line Id =  
Sta. 4+31.28, SWS I =  
€ Sta. 51+05.00, 45.00' Rt.

Sta. 0+89.25, End SWS Line Id =  
€ Sta. 51+05.00, 44.25' Lt.  
Construct Inlet (Single)(Type 1)  
(6'-4" x 4'-4")  
Install 15' x 89.25'  
Storm Sewer (RCP) (S)  
See Sh. No's 90, 96 & 97.

