



3. Where required, cut pavers with an approved cutter to fit accurately, neatly and without damaged edges.
4. Tamp pavers with mechanical vibrator until uniformly level, true to grade, and free of movement.
5. Fill joints with sand.

