



SW of Taft and Dugan - 515 S Dugan Rd



Attachment A - 472-85156 Bench and Shelter Installation, West Side Service, Wichita, KS

Install bench on existing pad. Refer to relevant details and General Notes. Bolt locations to anchor the bench are to avoid cracks and joints in the pad. Final location of the bench shall be coordinated with the Engineer.

W TAFT AVE

**Legend**

Improvement, Approx. Location



Approx. Property Line



5-ft Contours



1-ft Contours (NAVD88)



515

The Contractor shall pick up and install bench from Transit. Coordinate said activity as necessary with Philip Zevenbergen (phone: 316-352-4816, email: pzevenbergen). Work shall be performed per City details, the manufacturer's specifications, to City standards, or as directed by the Engineer or Zevenbergen.

S DUGAN RD

1309 1310

1311

1309

1307

1306

1306

1307

1308

1308

1307

1307

1308

1312

1308