


MICHELLE EARTHWORK SUMMARY

Total Volume Table						
Station	Fill Area	Cut Area	Fill Volume	Cut Volume	Cumulative Fill Vol	Cumulative Cut Vol
10+37.50	6.41	34.92	0.00	0.00	0.00	0.00
10+50.00	7.30	33.66	3.17	15.88	3.17	15.88
11+00.00	8.96	29.96	15.06	58.91	18.23	74.79
11+50.00	7.59	34.82	15.32	59.98	33.55	134.76
12+00.00	13.42	28.63	19.45	58.75	53.01	193.52
12+50.00	20.25	21.72	31.18	46.62	84.18	240.14
13+00.00	20.91	19.97	38.11	38.60	122.30	278.74
13+50.00	19.08	22.89	37.03	39.68	159.33	318.42
14+00.00	9.20	32.15	26.18	50.96	185.51	369.38
14+50.00	6.20	33.51	14.26	60.80	199.77	430.18
15+00.00	14.69	25.55	19.35	54.68	219.12	484.86
15+50.00	14.12	27.08	26.68	48.73	245.79	533.59
16+00.00	17.21	23.61	29.01	46.94	274.80	580.54
16+50.00	18.32	23.20	32.90	43.35	307.70	623.88
16+62.00	18.12	23.64	8.10	10.41	315.80	634.29


MICHELLE CIRCLE EARTHWORK SUMMARY

Total Volume Table						
Station	Fill Area	Cut Area	Fill Volume	Cut Volume	Cumulative Fill Vol	Cumulative Cut Vol
0+64.50	7.23	35.71	0.00	0.00	0.00	0.00
1+00.00	16.99	32.11	15.92	44.59	15.92	44.59
1+50.00	18.61	22.48	32.96	50.55	48.89	95.14
2+00.00	10.10	31.92	26.58	50.37	75.47	145.51
2+50.00	7.21	34.33	16.03	61.35	91.49	206.86
3+00.00	16.41	18.89	21.87	49.28	113.36	256.13
3+06.00	34.38	19.20	5.64	4.23	119.00	260.36

16+62.00



16+50.00



16+00.00

