

① $\angle A = \angle B = 90^\circ$
 ② $\angle A = \angle B = 120^\circ$
 ③ $\angle A = \angle B = 135^\circ$
 ④ $\angle A = \angle B = 150^\circ$
 ⑤ $\angle A = \angle B = 165^\circ$
 ⑥ $\angle A = \angle B = 180^\circ$
 ⑦ $\angle A = \angle B = 195^\circ$
 ⑧ $\angle A = \angle B = 210^\circ$
 ⑨ $\angle A = \angle B = 225^\circ$
 ⑩ $\angle A = \angle B = 240^\circ$
 ⑪ $\angle A = \angle B = 255^\circ$
 ⑫ $\angle A = \angle B = 270^\circ$
 ⑬ $\angle A = \angle B = 285^\circ$
 ⑭ $\angle A = \angle B = 300^\circ$
 ⑮ $\angle A = \angle B = 315^\circ$
 ⑯ $\angle A = \angle B = 330^\circ$
 ⑰ $\angle A = \angle B = 345^\circ$
 ⑱ $\angle A = \angle B = 360^\circ$

12. 12.10.1946
 12.10.1946 12.10.1946 12.10.1946 12.10.1946 12.10.1946
 12.10.1946 12.10.1946 12.10.1946 12.10.1946 12.10.1946
 12.10.1946 12.10.1946 12.10.1946 12.10.1946 12.10.1946

DRAINAGE AREA = 2.07
C = 0.9
Q_s = 3.5 cfs
Q_{sub} = 13.7 cfs

DRAINAGE AREA = 4.44
C = 0.9
 $Q_5 = 18.2$ cfs
 $Q_{100} = 29.5$ cfs

DRAINAGE AREA = 1.42
C = 0.75
Q_s = 4.9 cfs
Q₁₀₀ = 7.9 cfs

TIE-IN TO EXISTING CURB WITH
 PROPOSED CURB & GUTTER.

INSTALL CURB & GUTTER 6" NORTH OF EXISTING
CURB & GUTTER UTILIZING EXISTING PAVEMENT
TO FORM DRAINAGE FLUME.

INSTALL 4 - 6" DEETER TYPE #2449-6
CURB OUTLET OR, EQUIVALENT AT END
OF FLUME FOR OUTLET CONTROL.