








VEHICLE DETECTOR SUMMARY				
CAMERA NO.	ZONE NO.	LOOP SIZE W x L (Feet)	DETECTOR SETTING	PHASE CALLED
1	N1	60' x 90.0'	PRESNCE	3
1	N2	60' x 10.0'	PULSE	8
1	N3	18.0' x 6.0'	PULSE	8
1	N4	18.0' x 6.0'	PULSE	8
2	W1	60' x 48.0'	PRESNCE	5
2	W2	18.0' x 6.0'	PULSE	2
2	W3	18.0' x 6.0'	PULSE	2
2	W4	18.0' x 6.0'	PULSE	2
3	S1	60' x 90.0'	PRESNCE	7
3	S2	18.0' x 6.0'	PULSE	4
3	S3	18.0' x 6.0'	PULSE	4
3	S4	18.0' x 6.0'	PULSE	4
4	E1	60' x 35.0'	PRESNCE	1
4	E2	18.0' x 6.0'	PULSE	6
4	E3	18.0' x 6.0'	PULSE	6
4	E4	18.0' x 6.0'	PULSE	6



- TYPICAL LOOP DIMENSIONS -
 PRESENCE = 50.0' x 6.0'
 PULSE = Varies x 6.0'