



Moving channelizing devices and signs, and additional traffic control may be necessary to construct entrances. Maintain all weather access at all times during construction. This shall be considered Subsidiary.

- ① Provide temporary all weather access to entrance at all times during construction.
- ② Place channelizing devices as necessary during construction to restrict access to work area.

**LEGEND**

- Channelizing Device at 60' Spacing unless otherwise noted.
- Traffic Control Sign
- Type III Barricades
- ▨ Work Area (New Pavement)
- Direction of Traffic

Note: Signs and barricades are shown diagrammatically only. Contractor will be responsible to install the required number of posts to support the installation.

Note: Utilities are not shown on Traffic Control Plans. The Contractor is responsible for verification as to type and location of underground utilities as may be necessary to avoid damage thereto. The Contractor is responsible for repairing any damage to underground utilities.

Plotted By: svb Date: 2/6/2013 3:09:28 PM  
 FILE: I:\2010\10281\Traffic Control\10281-TC Stage2-211.dgn

No.	Revision	By	Date
135TH ST.			
<b>TRAFFIC CONTROL PLAN</b>			
STAGE 2 - STA. 211+00 TO STA. 235+00			
GARY JANZEN, P.E.-CITY ENGINEER CITY OF WICHITA PROJECT NO. 472-84915			
		PROFESSIONAL ENGINEERING CONSULTANTS, P.A. 303 SOUTH TOPEKA WICHITA, KS 67202 316-262-2691 www.pec1.com	
Designed by	JPS	Job No.	10281
Drawn by	SVB	Date	JAN, 2013
			Sht. 59 of 83