





The technical drawing illustrates the components of a microscope. It includes a front view (top left) showing the eyepiece, objective lenses, and the stage. A side view (bottom left) shows the base, column, and the stage with its clips. A detail view (right) shows the eyepiece and objective lenses with their respective mounting rings and adjustment screws. The drawing is a line drawing with no shading.

R 10-12
24" x 30"

LEFT TURN
YIELD
ON GREEN

SEE DETAIL "A" FOR MOUNTING
HARDWARE


60" x 18"

Street Name

Diagram illustrating the Pedal Indicator Assembly. The assembly includes the following components and dimensions:

- HINGE LEFT SIDE
- HINGE RIGHT SIDE
- 1 1/2" 10 PIPE
- STD. TEE FITTING
- STD. 90° ELBOW
- FASTENER ASSY FOR PED. INDICATION
- 130° COUNTER CLOCKWISE TO MACHINE

1. DIRECTIONAL ALIGNMENT OF PED. INDICATIONS & BRACKET(S) SHALL BE DETERMINED IN THE FIELD BY THE ENGINEER.
2. THROUGH HOLES IN THE POLE SHALL BE DRILLED AND WELL REAMED TO PREVENT CABLE CHAFING.
3. HINGE PEDESTRIAN SIGNAL DOORS AWAY FROM POLE.



- NOTE:
1. THE ANCHOR BOLTS FOR THE SIGNAL POLE SHALL BE TIED WELDED TOGETHER IN A 16" OR 20" DIA. BOLT PLATE (ON CENTERS AS SHOWN) TO MAINTAIN REQUIRED BOLT CONFIGURATION PATTERNS AND TO AID IN VERTICAL POSITIONING WHILE CONCRETE BASE IS POURED.
 2. USE ANTI-SEIZE COMPOUND ON ALL THREADS.
 3. 12" x 3/4" GROUND ROD TO BE POSITIONED BEFORE POURING BASE.
 4. CLASS "A" CONCRETE SHALL BE USED TO CONSTRUCT BASE.
 5. CONSTRUCT A 6" THICK x 36" SQUARE C&G CAP AFTER POLE HAS BEEN ERECTED & PLUMBED. CHAMFER EDGES 1/4" MUST BE APPROVED BY ENG. BEFORE POURED.
 6. CONDUIT SHALL HAVE PLASTIC (OR METAL) BUSHING BASED TO PREVENT CABLE CHAFING.
 7. USE #8 BARE COPPER GROUND CONDUCTOR FROM CLAMP TO GROUND BOLT IN ACCESS HOLE.