




LEGEND OF TEMPORARY
DITCH SILT CONTROL METHODS

- Silt Fence Ditch Check
- Straw or Hay Bale Ditch Check


NOTE: The usage of Straw or Hay Bales or Silt Fence is at the option of the Contractor. The symbols shown in the Typical Plan shall in no way be interpreted nor implied as to the usage of Ditch Check Types.

GENERAL NOTES

- STRAW OR HAY BALE NOTES:
- Place Bales tightly together, with loose straw or hay wedged between Bales to close off any openings.
 - Wood Stakes shall be 2" x 2" (nom.) x 4'-0" (min.) long.
 - Use as many Bales as necessary to completely block the entire width of ditch flowline, with excess Bale length cut into fore and back slopes.
 - Use as many Bales as necessary on fore and back slopes to insure water does not flow around barrier.
 - Use only twine to bind bales. The use of wire binding is prohibited because it does not readily biodegrade.


- SILT FENCE NOTES:
- Wood Stakes shall be 2" x 2" (nom.) x 4'-0" (min.) long.
 - Attach Fence Fabric to wood stakes with staples, wire, or nails.
 - Use as many wood stakes as necessary to achieve a maximum spacing of 5' across ditch cross section.

TEMPORARY DITCH CHECK SPACING	
DITCH @ SLOPE (%)	SPACING INTERVAL (Ft.)
1.0	200
1.5	133
2.0	100
2.5	80
3.0	66
3.5	57
4.0	50
4.5	44
5.0	40
5.5	38
6.0	35
6.5	30
7.0	28
7.5	26
8.0	25
8.5	23
9.0	22
9.5	21
10.0	20



STRAW OR HAY BALE DITCH CHECK

NO SCALE



SILT FENCE DITCH CHECK

NO SCALE

3

2

1

NO.

DATE

REVISIONS

BY

APP'D

3/13/97

Revised Straw/Hay Bale Ditch Check

WCL

RDR

KANSAS DEPARTMENT OF TRANSPORTATION

TEMPORARY PROJECT WATER POLLUTION CONTROL

STRAW OR HAY BALE DITCH CHECKS

SILT FENCE DITCH CHECKS

LA852E

F.H.W.A. APPROVAL

4/02/97

APP'D

Richard D. Ross

DESIGNED

WCL

DETAILED

DEL

QUANTITIES

TRACED

DESIGN

RDR

DETAIL

WCL

QUAN.

CK.

WCL

QUAN.

CK.

WCL

QUAN.

CK.

Drawn By: \$\$\$USERNAME\$\$\$
DGN File: \$\$\$DGN\$\$\$
Plotted: \$\$\$SYTIME\$\$\$ View: PLOT 1