




Save: 03-14-2008 8:10:20 AM by BLS
Plot Scale: 1"=20'-14-2008 10:25:13 AM by JMU
C:\2004\04485\000\SWSLINE3



COORDINATE LIST		
POINT	NORTH	EAST
500	26,385.1895	16,048.4380
501	26,372.7207	16,070.5669
502	26,299.4148	16,200.6657
503	26,298.6768	16,201.9754
504	26,282.8044	16,230.1448
505	26,282.0665	16,231.4545

500 = COORDINATE POINT NO.
SEE SHEET NO. 3 FOR PLAT COORDINATES



FONTANA ADDITION-PHASE 1
SWS LINE NO. 5

Professional Engineering Consultants, P.A.
303 S. TOPEKA - WICHITA, KANSAS 67202
316-262-2601 • FAX 316-262-3003

Designed By	BLB, BDB
Drawn By	BLS
Job No.	35-04485-000
Date	SEPTEMBER 2004